


— WELCOME TO —

TANGENTWOOD

Assembly Instructions



JOHNSON BAY ADIRONDACK CHAIR

Thank you for your purchase of Tangentwood furniture. If you have any questions or need assistance with assembly, please contact our customer care team through our website or email us at info@tangentwood.com.

Tangentwood Brands Include:

DUROGreen®
MADE WITH TANGENTWOOD



Thank you for choosing Tangentwood!

We create strong, stylish and sustainable furniture to elevate your outdoor living. Our all-weather outdoor furniture is made from durable Tangentwood, the most luxurious HDPE lumber available. Our furniture comes with a commitment to excellence shown through our 20-year limited residential warranty. Rest easy knowing your all-weather chair will look this good for years to come.

TANGENTWOOD

TANGENTWOOD

Furniture made with Tangentwood is designed to stay outdoors all year round.

No maintenance required. Tangentwood will not crack, peel, warp or splinter. It never needs staining, waterproofing or painting.

Tangentwood furniture is made with recycled plastic and marine-grade stainless steel hardware.









Simply clean with soap and water.

Tangentwood furniture is tested to the BIFMA 5.1 standard. Weight capacity: 300lbs







Proudly made in the USA.

Ships ready to assemble with easy step-by-step instructions.




COMPONENT LIST

| ITEM | PICTURE | DESCRIPTION | QTY. |
|------|---|----------------------|------|
| A |  | Back | 1 |
| B |  | Seat Assembly | 1 |
| C |  | Left Front Leg | 1 |
| D |  | Right Front Leg | 1 |
| E |  | Left Arm | 1 |
| F |  | Right Arm | 1 |
| G |  | Back Brace | 1 |
| H |  | Front Brace (Longer) | 1 |

HARDWARE LIST


| ITEM | PICTURE | DESCRIPTION | QTY. |
|------|---|---|------|
| H-1 |  | Lag Screw 1/4" x 2-1/2" | 4 |
| H-2 |  | Small Machine Screw 1/4"-20 x 1-7/8" | 6 |
| H-3 |  | Large Machine Screw 1/4"-20 x 2-1/4" | 2 |
| H-4 |  | Phillips Screw #8 x 1-1/2" | 4 |
| H-5 |  | Nylon Lock Nut | 8 |
| H-6 |  | Washer | 8 |

TOOL LIST

| ITEM | PICTURE | DESCRIPTION | QTY. |
|------|---|---|------|
| T-1 |  | T-Handle Allen Wrench | 1 |
| T-2 |  | #2 Phillips Screwdriver (Not Included) | |
| T-2 |  | 7/16" Wrench (Not Included) | |

ASSEMBLY PREPARATION

Before
Beginning:



Unpack all hardware bags and components to ensure you have all parts. Take note of bolt hardware size differences and components that may have directional labels (Example: TOP or FRONT).




Read the assembly instructions, cover to cover.



It is always recommended to have two adults on hand for assembly.



Do not assemble on hard, abrasive flooring or carpeted surfaces that can damage or get caught in the components during assembly.



Assemble on a clean, non-marring surface.



Do not discard any packaging until the product has been fully assembled.



In case of missing parts, please email our customer care team at info@tangentwood.com.




WARNING: Small parts are a choking hazard. Adult supervision is required before, during and after assembly.


Step 1 Installing the Front Brace



(H-4) Phillips Screw x 2



(T-2) Phillips Screwdriver



Install the longer Front Brace (H) into the Right Front Leg (D).
Fasten using the Phillips Screw (H-4) with a Phillips Screwdriver (T-2).
Fit the longer Front Brace (H) into the Left Front Leg (C).
Fasten using the Phillips Screw (H-4) with a Phillips Screwdriver (T-2).
Do not yet fully tighten.

IMPORTANT:

Use the longer Front Brace (H),
instead of the shorter Back Brace (G).


Step 2 Installing the Back



(H-1) Lag Screw x 2



(T-1) T-Handle Allen Wrench




Install the Back (A) by fitting it into the pockets of the back of the Seat Assembly (B). Fasten using a Lag Screw (H-1) on each side with the T-Handle Allen Wrench (T-1). Do not yet fully tighten.

Step 3 Installing the Back Brace

 (H-4) Phillips Screw x 2

 (T-2) Phillips Screwdriver




Install the shorter Back Brace (G) into the pockets of the Seat Assembly (B). Fasten using a Phillips Screw (H-4) with a Phillips Screwdriver (T-2) on each side. Do not yet fully tighten.

IMPORTANT:

Use the shorter Back Brace (G), instead of the longer Front Brace (H).


Step 4 Installing the Front Legs


 (H-2) Small Machine Screw x 6

 (H-5) Nylon Lock Nut x 6

 (H-6) Washer x 6

 (T-1) T-Handle Allen Wrench

 (T-3) 7/16" Wrench




Align the three holes in the front leg assembly with the front of the Seat Assembly (B). Insert three Small Machine Screws (H-2) into the holes on each side and using the Nylon Lock Nut (H-5) and Washer (H-6) stacking the hardware in the order as shown on the inside of the seat. Tighten the screws with the T-Handle Allen Wrench (T-1) while holding Nylon Lock Nut (H-5) in place with the 7/16" Wrench (T-3). Complete for both sides.


Step 5 Installing the Arms


 (H-3) Large Machine Screw x 2

 (H-5) Nylon Lock Nut x 2

 (H-6) Washer x 2

 (T-1) T-Handle Allen Wrench

 (T-3) 7/16" Wrench



Rest the Left Arm (E) on the Left Front Leg (C) and left side of the Back Brace (A). The arm should be on the outside of the leg. Fasten the arm down using a Large Machine Screw (H-3) on the leg side and tighten using the Nylon Lock Nut (H-5) and Washer (H-6) under the arm. Tighten the screws with the T-Handle Allen Wrench (T-1) while holding the Nylon Lock Nut (H-5) in place with the 7/16" Wrench (T-3). Do not yet fully tighten. Repeat this process for the Right Arm (F).


Step 6 Installing the Arms



(H-1) Lag Screw x 2



(T-1) T-Handle Allen Wrench



Fasten Left Arm (E) and Right Arm (F) to the Back Brace (A) using a Lag Screw (H-1) on either side with the T-Handle Allen Wrench (T-1). Fully tighten all hardware from this step and all previous steps. **DO NOT OVER TIGHTEN.**

Step 7 Completed

TANGENTWOOD



Assembly is now complete and the product is ready for use.

NOTE: Hardware may loosen over time. Periodically check that all connections remain tight and adjust as needed.